

Excessive neutral current, resulting in overheated neutrals. The odd triplen harmonics in three phase wye circuits are actually additive in the neutral. This is because the harmonic number multiplied by the 120 degree phase shift between phases is a integer multiple of 360 degrees. This puts the harmonics from each of the three phase legs “in-phase” with each other in the neutral.

