



The mosfet drive grounds are floating
Never connect to power ground.



STEAP Input power. © 2026 M. J. Nunnerley

Sheet: /
File: STEAP start and run power supply.kicad_sch

Title:

Size: A4
KiCad E.D.A. 9.0.3

Date: 14/01/2022

Rev: 01/06/2026

Id: 1/1